

Big Wally's
PLASTER MAGIC
FOR THE **ULTIMATE PLASTER REPAIR**

Technical Bulletin

Big Wally's Plaster Magic—the Ultimate Repair Adhesive®

Interior and Exterior Plaster Reattachment
Secures Plaster and Stucco to Wood Lath or Masonry
Simple to Use
Easy Clean-up With Water
Primer Assures Professional Results
Low Odor
Penetrating Bond
Strong and Flexible
Professional Grade

Packaging:

Contractors Pack: 15/10 oz. cartridges adhesive, 2/32 oz. spray bottles conditioner, 50 plastic clamps and screws, 2 pairs disposable gloves.

Painters Pack: 6/10 oz. cartridges of adhesive, 1/32 oz. spray bottle conditioner, 25 plastic clamps and screws, one pair disposable gloves.

Homeowners Pack: 3/10 oz. cartridges of adhesive, 1/16 oz. spray bottle conditioner, 25 plastic clamps and screws, one pair disposable gloves.

Company Identification:

Manufacturer: Big Wally's Adhesives, Inc., P.O. Box 1084, Brattleboro, VT 05302
Usage Information: 802-254-1330, 8 am–5 pm Mon-Fri (Eastern Time)
Order Information: 802-254-1330, 8 am–5 pm Mon-Fri; 9 am–12 pm Sat (Eastern Time)
Web Site: www.plastermagic.com
E-Mail: info@plastermagic.com

Product Description:

Big Wally's Plaster Magic—the Ultimate Repair Adhesive® is a professional grade adhesive that was designed to reunite historic plaster to its lath. It works as an interior and exterior adhesive and bonds most common building materials.

Suggested Use:

Secures and stabilizes historic plaster and stucco.

Surface Preparation & Application:

For plaster reattachment: drill 3/16" holes through plaster to the lath. Spray conditioner (under pressure) into holes to coat the plaster on the reverse and the lath (conditioner consolidates surface dirt inside walls). Wait ten minutes, then inject adhesive into the same holes. Clamp with screws and clamps through some of the holes to bring the plaster gently back to its original plane. Remove the screws and clamps after the adhesive has set, within 24 to 48 hours. Fill drill holes with ready mixed, all-purpose joint compound or plaster. Finish surfaces as desired.

For Best Results:

Surfaces must be clean and dry. Prime surfaces with conditioner to be adhered then wait ten minutes before applying the adhesive; do not wait so long that the conditioner has time to dry. If the later is the case, then reapply more conditioner before applying the adhesive.

Physical & Chemical Characteristics:

The adhesive is a resin-based, acrylic emulsion. It has a thick, shaving cream consistency that is white when wet, turning translucent when cured. The conditioner is a thin, liquid, acrylic mixture; it is white when wet and dries clear. Both must be kept from freezing.

Clean Up:

This conditioner and adhesive (uncured) cleans up with warm water. Cured adhesive must be scraped off with a sharp blade or putty knife.

Safety:

Avoid skin and eye contact—wear waterproof gloves and eye protection.
Provide proper ventilation.
Protect surrounding area.
Contact may ruin clothing and adjacent architectural features.
May be harmful if swallowed.
Keep out of reach of children and pets.
First aid: for eye contact—flush with water for 15 minutes, call physician.
Keep from freezing.